

Technical Specification of Cooling curve

To study of Tin – lead phase diagram

Set up consist of

- 1 Vertical furnace up to 400°C (LC – 0.1°C)
- 2 Thermocouple with protective insulation sheath.
- 3 Lead and Tin granules .
- 4 Silica crucibles.
- 5 Stop Watch.
- 6 Stirring Rod.